



PRISM

felt wall






HOW TO SPECIFY

Combine artistry and functionality with Prism. The precision-cut slats effectively absorb sound, creating a more peaceful atmosphere while adding style to any space. Reduce unwanted noise and echo with Prism acoustic felt walls.

Available in ombrés, standard colors, woodgrains, and custom colors with SHADES by MPS.

01


SPECS



Tell us about your space, the design, and dimensions.

02


COLORS




Standards. Woodgrains. Customs.
What's your color? (See page 6)

03

MAKE IT YOUR OWN!



Spec your own slat size and orientation.
Add end caps and/or ledge pieces. (See page 4)

SHADES by  MPS™

PANTONE

PANTONE GRADIENT

WOOGRAINS & PRINT

Spec your own color, gradient, or
woodgrain. (See page 6)




PRODUCT SPECIFICATIONS

STANDARD DIMENSIONS

Single Panel 23"W x 119"H

Felt Thickness 2"



*Customize width using 23" standard panels



PRODUCT SPECIFICATIONS

CONNECTION


Screws concealed by slats.

ADDITIONAL OPTIONS


End Caps: Finished mitered end caps to conceal stand-offs.

Ledge Pieces: Mitered back panel folded return edge to conceal stand-offs.


PRISM PANEL



END CAPS



LEDGE PIECES





TECHNICAL SPECIFICATIONS



Absorption

Standard: .85 NRC

(subject to mounting conditions)

Fire Rating

ASTM E84 Class A

Warranty

Two (2) Years

VOC

ASTM D5116 Compliant

Material

100% PET acoustic felt

Maintenance

Vacuum clean to remove dust
and debris

Sustainability





COLORS & WOODGRAINS

MPS offers a range of standard ombrés, colors, woodgrains, and custom colors with SHADES.


STANDARD OMBRÉS



STANDARD COLORS



SHADES by MPS



Your design world revolves around color, so don't be limited by standard colors and outdated palettes. SHADES offers Pantone options, full-color prints, and unique gradients. Flat or Heathered? Your choice. *Some limitations apply. Consult your MPS acoustics expert to discuss your project.

WOODGRAINS





MOUNTING OPTIONS

TOOLS REQUIRED



Cutting tool



Steel straightedge




Drill



Screws

DRY FIT

Before screwing in backer, dry fit the first panel to the wall.



Note: to avoid irregularity, we recommend applying to the top of a baseboard.



MOUNTING OPTIONS

MOUNT WITH SCREWS

Screw the backer panel to the wall, ensuring that each screw is drilled through the horizontal acoustic enhancers that are on the back side of each backer panel.

