


RUMUR





HOW TO SPECIFY

Rumur acoustic panels are flat wall-mounted geometric shapes that provide beautiful inspirational energy, reflecting the colors of the workspace, while providing significant sound absorbing benefits.



Tell us about your space, the design, and dimensions.

SHAPE






What shape does your design call for? Square, rectangle, or both?

03 COLORS



Standard. Woodgrains. Customs. What's your color? (See page 6)

04 MAKE IT YOUR OWN!



Choose one of our patterns or spec your own. (See page 4)

SHADES by $\boxtimes MPS$




Spec your own color, gradient, or woodgrain. (See page 6)



PRODUCT SPECIFICATIONS

STANDARD DIMENSIONS

Standard Square $7 \frac{3}{4}$ " x $7 \frac{3}{4}$ " and $11 \frac{3}{4}$ " x $11 \frac{3}{4}$ " Standard Rectangle $7 \frac{3}{4}$ " x $15 \frac{3}{4}$ " and $11 \frac{3}{4}$ " x $23 \frac{3}{4}$ "





PRODUCT SPECIFICATIONS

DESIGNS

Rumur comes in nine square and nine rectangle designs, or customize your Rumur with your own design.

Square



X

2S Petal



3S Kiss









Rectangle



2L Petal



3L Kiss

Н








1L Tao





6S Stack

7S Bloom

8S Spin

9S Current


4L Hop

5L Star

6L Stack







7L Bloom

8L Spin

9L Current



TECHNICAL SPECIFICATIONS



Absorption

Standard: .85 NRC

(subject to mounting conditions)

Fire Rating

ASTM E84 Class A

Warranty

Two (2) Years

VOC

ASTM D5116 Compliant


Material

PET Felt: 100% polyester fiber

Maintenance

Vacuum clean to remove dust and debris

Sustainability

















COLORS & WOODGRAINS

MPS offers a range of standard colors, woodgrains, and custom colors with SHADES.

STANDARD COLORS



WOODGRAINS



SHADES by ${\mathbb B} MPS$



Your design world revolves around color, so don't be limited by standard colors and outdated palettes. SHADES offers Pantone options, full-color prints, and unique gradients. Flat or Heathered? Your choice.

*Some limitations apply. Consult your MPS acoustics expert to discuss your project.



MOUNTING OPTIONS

TOOLS REQUIRED



Cutting tool

Steel straightedge



--


Hole saw




Construction adhesive

DRY FIT

Before applying adhesive, dry fit the first panel to the wall.






Note: to avoid irregularity, we recommend applying to the top of a baseboard.




MOUNTING OPTIONS


APPLY CONSTRUCTION ADHESIVE (RECOMMENDED)



With acoustic enhancers

Without acoustic enhancers





HOOK Z-CLIPS (ALTERNATIVE)

Determine the desired position of z-clips and screw them into the back of the panel.

